



PVC SCH40 Installation Instructions

EASY STEPS FOR INSTALLING PVC SCH40 FITTINGS

1. Measure and mark the PVC pipe where you will be installing the fittings. Use the measuring tape to get accurate measurements, and mark the pipe with a marker.
2. Cut the PVC pipe to the desired length using the PVC pipe cutters or a saw. Make sure to cut the pipe as straight as possible to ensure a secure fit.
3. Deburr the cut.
4. Use the PVC primer on the outside of the pipe and the inside of the fitting. Apply the primer using a clean cloth, and make sure to cover the entire surface.
5. Apply the PVC cement to the outside of the pipe and the inside of the fitting. Be sure to apply the cement evenly and cover the entire surface.
6. Quickly insert the fitting onto the pipe, twisting it slightly to ensure a tight fit. Hold the fitting in place for 30 seconds to allow the cement to dry.
7. Repeat the above steps for each additional fitting that needs to be installed.
8. Allow the cement to dry completely. This may take several hours depending on the temperature and humidity.
9. Test the fittings to make sure they are secure and leak-free. Turn on the water supply and inspect the fittings for any leaks or signs of damage.
10. If necessary, make any adjustments or repairs to ensure a secure and leak-free installation.

